

## Generator

### ENGINE

Piston, piston rings, wrist pins, piston retaining clips, connecting rods, connecting rod bearings, connecting rod bolts, main bearings, main bearing bolts, crankshaft, crankshaft sprockets, camshaft, camshaft bearings, intake valves, exhaust valves, valve seats, valve springs, valve spring retainers, valve guides, push rods, lifters, rocker arms, timing chain, timing gears, timing belt, timing cover, timing cover seal, timing cover gasket, valve cover, valve cover gasket, harmonic balancer, oil pump, oil pan, oil pan gasket, distributor housing, distributor shaft and bearings, head gasket, flywheel, engine circulation pump, fuel pump, warning horn sensor and alarm, seals, gaskets.

### ELECTRICAL

Switch box, alternator, voltage regulator/rectifier, ignition coil, starter, starter solenoid, engine wiring harness, bilge blower.

### GENERATOR ELECTRICAL

Armature, fields, brushes, end frame and housing, rectifier, generator-mounted control panel, generator remote control panels, control panel gauges.

Administered by

# ServiceGuard Systems, Inc.

**Toll Free 888-464-3774**

[ssi@service-contract.com](mailto:ssi@service-contract.com)

Except in Florida where the Administrator is Dealers Assurance Company, 15920 Addison Road, Addison, TX 75001, FL License #02977, Toll Free 844-865-6781. Replacement parts may be new, used or remanufactured.

This brochure should not be relied upon when purchasing coverage. Please refer to the ESC contract for specific coverage details. Changes may have been made to the ESC program since the printing of this brochure. All transactions related to the ESC program are governed solely by the provision of the contract.

## Outboard

### ENGINE

Pistons, piston rings and pins, main bearings and rod bearings, crankshaft, connecting rods, camshaft, camshaft bearings, valve springs, guides, lifters, rocker arms, valve spring retainer, valve cover, oil pump, oil filter housing, reeds and reed blocks and flywheel. Engine head(s), engine block and/or cylinder barrels if damaged as a result of a covered of an above listed component.

### FUEL SYSTEM

Electric choke solenoid (enrichener). Electronic fuel injector delivery pumps (high and low pressure), fuel injectors, fuel rails, ECU module, pressure regulator, mechanical fuel pump.

### LUBRICATING SYSTEM

Oil injection pump, oil pump drive gear, oil pump drive shaft, oil tank, oil tank cap, oil level warning horn and lights, oil injection check valves.

### LOWER UNIT

Forward gear, reverse gear, pinion gear, clutch dog, dog pin, cam follower, prop shaft, drive shaft, bearing carriers, bearings, shims, shift shaft. Gear housing if damaged as a result of a covered failure of an above listed component.

### JET DRIVE

Drive shafts, shaft bearings, reverse gate, shifts cams. Housing only if damaged as a result of a covered failure of an above listed component. Note: Does not include jet impellers.

### STEERING

Control helm assembly, control rack and yoke assembly, power steering pump, power steering cylinder, steering wheel. (Main Station Only).

### CONTROLS

Manual and electronic shift and/or throttle control box components to include: cams, eccentrics, shafts, pivots, bushings, housing, control arms/levers and knobs, starter/stop button, tether switch, neutral safety switch, joystick, thrust vector module and cylinder. Shift control cable, throttle control cables, shift and throttle micro switches, potentiometer, control panel and wire harness (Main Station Only).

### ELECTRICAL SYSTEM

Alternator, voltage regulator/rectifier, engine mounted wiring harness, OEM ignition switch, starter motor, starter armature, starter field windings, starter magnets, brush holders and brushes, end caps and bushings, starter drive, starter solenoid, power pack/switch box, electronic ignition module, timer base, trigger assembly, ignition coil, capacitor discharge module.

### POWER TRIM/TILT

Trim and/or tilt motor, trim cylinders, cylinder rams, cylinder mounts and pivots, trim motor actuator solenoids, pump, trim and/or tilt wiring harness, trim and/or tilt master control switches, trim limit switch, trim position sender.

### DIRECT FUEL INJECTION

Air injectors, fuel injector, air compressor, tracker valve, fuel regulator, fuel rails, check valve, mechanical fuel pump, low and high pressure fuel pump, vapor separator.

## BENEFITS

### HOIST/LIFT-OUT

Hoist/Lift-Out provided to facilitate covered repairs

### TOWING

Towing reimbursement anytime a covered component fails causing the craft to be towed either in the water or on land.

## Accessory Packages

### RUNABOUT

Digital depth finder, fish finder/gps, electric trolling motor, electrical, stereo, gauges, anchor, VHF radio, waste system, water system, trim tabs, sunshade, bilge, power poles, live well/bait well, power transom/manual transom, controls, steering, controls, steering, trailer

### WAKE

Ski and wakeboard tower, wake shaping, cruise control, ballast, digital depth finder, electrical, stereo, gauges, GPS, VHF radio, water system, lighting, cockpit heat exchanger, trim tabs/planing system, sunshade, bilge, anchor, power poles, controls, steering, trailer.

### PONTOON

Digital depth finder, fish finder, electric trolling motor, electrical, stereo, gauges, GPS, VHF radio, refrigerator, water system, lighting, trim tabs, sunshade, bilge, anchor, power poles, live well/bait well, controls, steering, trailer.

### DAYBOAT

Air conditioner, digital depth finder, electrical, stereo, gauges, GPS, VHF radio, refrigerator, ice maker, horn, waste system, water system, lighting, spotlight, trim tabs, sunshade, bilge, power poles, windlass, trailer.

### SPORT FISHING

Air conditioner, digital depth finder, fish finder/GPS, electric trolling motor, power transom, electrical, stereo, gauges, VHF radio, down riggers, water system, trim tabs, sunshade, bilge, power poles, live well/bait well, windlass, controls, steering, trailer.

### OFFSHORE SPORT FISHING

Air conditioner, digital depth finder, fish finder/GPS, electric trolling motor, power transom, electrical, stereo, gauges, VHF radio, down riggers, water system, waste system, lighting, shore power, refrigerator, freezer, galley cook top, microwave oven, ice maker, horn, spotlight, trim tabs, sunshade, bilge, power poles, live well/bait well, windlass, controls, steering, joystick, trailer.

### TROPHY FISHING

Air conditioner, digital depth finder, fish finder/gps, electric trolling motor, power transom, electrical, stereo, television, gauges, VHF radio, down riggers, water system, waste system, lighting, shore power, refrigerator, freezer, galley cook top, cockpit grill, microwave oven, fish box ice maker, cockpit bait freezer, horn, spotlight, trim tabs, sunshade, bilge, power poles, live well/bait well, cable master, oil exchange pump, windlass, controls, steering, joystick, trailer.

### CAPTAIN'S

Air conditioner, digital depth finder, electrical, stereo, gauges, vhf radio, water system, waste system, lighting, shore power, refrigerator, freezer, galley cook top, grill, microwave oven, ice maker, horn, 12 volt/24 volt, spotlight, trim tabs, sunshade, bilge, power poles, windlass

### CRUISER

Air conditioner, digital depth finder, electrical, stereo, gauges, VHF radio, water system, waste system, lighting, shore power, refrigerator, freezer, galley cook top, grill, microwave oven, ice maker, clothes washer/dryer, central vacuum, trash compactor, horn, 12 volt/24 volt, spotlight, swim platform, windshield defogger/cockpit heater, trim tabs, sunshade, bilge, power poles, windlass.

### YACHT

Air conditioner, digital depth finder, electrical, stereo, television, gauges, VHF radio, water system, waste system, lighting, shore power, refrigerator, freezer, galley cook top, grill, microwave oven, ice maker, clothes washer/dryer, central vacuum, trash compactor, horn, 12 volt/24 volt, spotlight, swim platform, windshield defogger/cockpit heater, trim tabs, sunshade, bilge, power poles, cable master, oil exchange pump, passerelle/tender crane, windlass

### NAVIGATION

Auto pilot, day/night camera, electronic compass, GPS, radar, satellite weather module.

### CHILLER AC

Chiller air conditioner.

### STABILIZATION

Brake system, electrical, cooling, foundation frame.

## ADDITIONAL OPTIONAL COVERAGE

Optional package coverage only applies if you have paid the issuing dealer an optional package surcharge and it is checked under "Surcharges" on the Registration Page. If you have purchased an optional coverage, the components/parts listed for that specific coverage are covered by this ESC. Components not listed are not covered.



# Service Contract



## Gas & Diesel Inboard and Stern Drive

### ENGINE

Pistons, piston rings and pins, main bearings and rod bearings, crankshaft, connecting rods, camshaft, camshaft bearings, timing chain, timing gear cover, gears and/or belt, rocker arm(s), valve springs, valve guides, valve push rods, valve spring retainers, lifters, oil pump, oil filter housing. Valve cover(s), harmonic balancer, engine mounts, and flywheel. Distributor, engine water coolant circulating pump, coolant heat exchanger. Engine head(s), engine block and/or cylinder barrels, intake manifolds only if damaged as a result of a covered failure of an above listed component.

### TRANSMISSION

Clutch plates, thrust plates, planetary gears, shift bands, clutch drums, reduction gears, bearings, shafts, bearing carriers, hydraulic pumps, valve bodies, hydraulic pistons, neutral safety switch, control valves, transmission oil cooler, shift pressure transducer and transmission mounts. Transmission case if damaged as a result of a covered failure of an above listed component.

### FUEL SYSTEM

Fuel injectors, fuel rails, ECU module, pressure regulator, high pressure pump, low pressure pump, fuel management control unit, wiring harness repairs, fuel cooler, vapor separator (VST).

### UPPER HOUSING

Upper drive gears set, clutch dogs/cones, shift cams, bearings, shims, bearing carriers, upper drive shaft, spring kit. Upper case housing if damaged as a result of a covered failure of an above listed component.

### LOWER UNIT

Forward gear, reverse gear, pinion gear, clutch dog, dog pin, cam follower, prop shaft, drive shaft, shift shaft, bearing carriers, bearings, shims. Gear housing if damaged as a result of a covered failure of an above listed component.

### V-DRIVE

Bevel gears, bearings, shafts, shims, bearing carriers, friction and steel clutch plates, pressure plates, clutch drum, springs, control valve, regulator valve, hydraulic pump, neutral safety switch, ring gear, V-Drive oil cooler, shift pressure transducer. V-drive case if damaged as a result of a covered failure of an above listed component.

### MANUAL / HYDRAULIC STEERING

Control helm assembly, control rack and yoke assembly, power steering pump, hydraulic steering cylinder, power steering pump pulley, hydraulic steering pump, power steering oil cooler. (Main station only).

### CONTROLS

Manual and electronic shift and/or throttle control box components to include: cams, eccentrics, shafts, pivots, bushings, housing, control arms/levers and knobs, starter/stop button, tether switch, neutral safety switch, joystick, thrust vector module and cylinder. Shift control cable, throttle control cables, shift and throttle micro switches, potentiometer, control panel and wire harness (Main station only).

### ELECTRICAL SYSTEM

Alternator, voltage regulator/rectifier, engine mounted wiring harness, electrical choke element, OEM ignition switch, starter motor, starter armature, starter field windings, starter magnets, brush holders and brushes, end caps and bushings, starter drive, starter solenoid.

### INTERMEDIATE HOUSING

Intermediate shaft, U-joints, center yoke, drive yoke, gimbal bearings, steering yoke, engine coupler, intermediate shift cable. Intermediate housing/gimbal housing if damaged as a result of a covered failure of an above listed component..

## ADDITIONAL COVERAGE FOR INBOARD AND GAS STERN DRIVE

### IGNITION

Ignition module, ignition trigger coil, ignition high output coil, shift interrupter switch.

### POWER TRIM/TILT

Trim and/or tilt motor, trim cylinders, cylinder rams, cylinder mounts and pivots, trim motor actuator solenoids, reverse lock valve, pump, trim and/or tilt wiring harness, trim and/or tilt master control switches, trim limit switch and trim sender.

## PWC/Sport Boat

### ENGINE

Pistons, piston rings and pins, main bearings and rod bearings, crankshaft, connecting rods, camshaft, camshaft bearings, valves, valve springs, guides and seats, intake manifold, reeds and reed blocks. Exhaust metering valve, springs and diaphragm. Timing chain, gears and/or belt, flywheel. Engine head(s), engine block and/or cylinder barrels, only if damaged as a result of a covered failure of an above listed component.

### FUEL SYSTEM

Fuel delivery pump (mechanical/diaphragm), air box (silencer), supercharger, electric choke solenoid (enrichener). Electronic fuel injector delivery pumps (high and low pressure), fuel injectors, fuel rails, fuel distributors, ECU module, throttle position sensor, manifold air temperature sender, idle speed control, mass air flow sensor, detonation/knock sensor, ignition pickup sensor.

### JET DRIVE

Drive shaft, shaft bearings, shaft coupler, flex disc. VTS motor, VTS box, VTS shafts, VTS gauge and switch. Housing only if damaged as a result of a covered failure of an above listed component.

### STEERING

Control helm assembly, control rack and yoke assembly, column u-joint, steering gate, rudder, nozzle and pulleys.

### IGNITION

Power pack/switch box, amplifier, ignition trigger coil, ignition high output coil, spark plug wires, rev limiter.

### CONTROLS

Cams, eccentrics, shafts, pivots, bushings, housing, control arms/levers and knobs, shift control cable, throttle control cable and ignition switch.

### ELECTRICAL SYSTEM

LCD Gauge Assembly, alternator/stator, voltage regulator/rectifier, engine mounted terminal blocks, engine mounted wiring harness, electric choke solenoid, ignition switch, starter motor, starter armature, starter field windings, starter magnets, brush holders and brushes, end caps and bushings, starter drive, starter solenoid.

### LUBRICATING SYSTEM

Oil injection pump, oil pump drive gear, oil pump drive shaft, oil tank, oil tank cap, oil level sensors, oil level warning horn and lights, oil injection lines, oil injection check valves, oil injection metering system

### TRAILER

Frame rails, wheel bearings, spindles and springs, winch stand, welds, axle, hubs, coupler. Bunk and/or roller cradles.

## Avoid Costly Repairs

**\*300HP PRICING**

Component	Price
POWER HEAD	\$9,807
ALTERNATOR	\$705
POWER TRIM MOTOR	\$1,563
LOWER UNIT ASSEMBLY	\$3,491
STARTER	\$841
FUEL INJECTOR RAILS	\$861
FUEL CONTROL MODULE	\$1,285
BEARING CARRIER	\$797
STERNDIVE REPLACEMENT	\$8,998
UPPER DRIVE GEAR SET	\$1,834
POWER TRIM CYLINDER	\$1,285
DRIVE SHAFT HOUSING ASSEMBLY	\$7,231
LOWER GEAR CASE HOUSING ASSEMBLY	\$5,259
BEARING CARRIER	\$1,435
PROPULSION CONTROL MODULE	\$2,336
COUPLER	\$1,850
HEAD GASKET	\$1,312
LONG BLOCK	\$16,371
CRANKSHAFT	\$3,299
TURBO CHARGER	\$3,724
ENGINE CONTROL MODULE	\$2,964
ALTERNATOR	\$1,490
STARTER	\$1,075
ENGINE REPLACEMENT	\$45,485
HEAD GASKET	\$2,102
CRANKSHAFT	\$6,268

## ELITE ENGINE COVERAGE

### (Eligible New Engines Only)

Covers all components on your Engine except components/items listed in the "What is Not Covered" section of your contract.